

NEW Slot & Lock system





Slot & Lock Quadrant shower enclosure

Now installing a shower enclosure has never been easier. The stylish Slot & Lock Quadrant from Aqualux is a new concept for the UK market. Using the innovative Slot & Lock system, it is the first in a series of unique, screwless enclosures, which take as little as 5 minutes to assemble.* The enclosure is supplied with an easy plumb shower tray and shower column for easy access.

*Excluding plumbing

Product Features

- Stylish opaque glass panels and central control panel, finished with clear glass doors
- 4 adjustable body jets, positioned to massage neck, shoulders, back and lower back
- Chrome finish multi-function shower head and riser rail
- Chrome storage rack creating handy storage for soaps, shampoos and shower gels
- Aqualux branded chrome plated door handles
- Integral easy reach soap dish

adrajút trá s

Product Specfication

- Size: 900mm x 900mm
- Enclosure height: 1900mm (without tray)
- Tray height 140mm, including easy plumb fittings
- 6mm toughened safety glass
- Waste provided to fit 38mm diameter pipe
- Polished Silver effect aluminium profiles
- Chrome plated mouldings
- Easy clean detachable doors
- Packaging; supplied in 4 boxes;
 Box 1 Side Panels and Doors 44kg
 Box 2 Back Panels 41kg
 Box 3 Glass Column 17kg
 Box 4 Tray & Rails 15kg

Plumbing

- Hot and cold connectors
- Bar pressure 1.5 3 Bar

See how
easy the
Slot & Lock
Quadrant is to install on
the installation DVD at
www.aqualux.co.uk

 Product Code
 Description
 Size
 Height
 Colour
 Glass

 FEN0930AQU
 Slot & Lock Quadrant
 900mm x 900mm
 1900mm
 Polished Silver
 Clear

Start:





Place the tray on the floor. Use a spirit level and adjust the feet to ensure the tray is flat.



The central control panel and two back panels are in place.



9 Slide the clips across. These are located at the end of each rail, top and bottom.



2 Using a silicone gun, insert silicone into 4 holes positioned on the perimeter of the top of the tray.



Insert the central control panel into the rear 2 holes positioned at the back of the tray.



The two back panels must be in-line with the central panel before you slot and lock. The pin on the end of each panel locates into the hole on the front of the tray.



6 Lay the bottom rail on the tray. Ensure rail clips are unlocked.



Add the 2 clear glass side panels. They must be in-line with the back panels before you slot and lock into position.



Put on the top rail and slot into place.



Hang the doors on the top rail using the top bearings.



On the bottom bearings depress the section above the rollers to locate the bearings into the bottom rail.



Hang the shelving basket on the back panel.



Attach the shower hose and position the shower head.



On the rear of the unit, silicone between the tray and glass panels.

Also silicone from the base up 150mm, where the panels interlock.



15 Clip the top caps into place.



Push fit the wall seals on either side of the unit.



Mark up and fix the wall bracket to secure the unit to the wall.



Push fit the tray skirt and seal around the front of the enclosure using silicone.

18





Aqualux Products Limited, Universal Point, Steelmans Road, Wednesbury, West Midlands WS10 9UZ Tel: 0870 241 6131

Fax: 0870 241 6132 www.aqualux.co.uk



